



GRN20

Hold in place with supplied cable ties if necessary.




RootSpace® Leg

Start at the centre of the tree pit working outward.



ArborGuy

Position ArborGuy system as per product instructions.



RootSpace® Lid

Install lids around tree pit perimeter first.



Manifold

Sits on top of the RootSpace® lids, underneath the GLTWGNA



120mm Pipe

Please cut to correct height.




ArborVent 150

Finished flush with the paving surface level.



RootDirector


Placed on open aperture of tree pit.



GLTWGNA


Laid on top of RootSpace lids after soil filling.

ROOTSPACE® INSTALL INSTRUCTIONS




Drainage layer minimum depth 150mm, ideal depth 200mm. **MUST** be washed 10-20mm angular aggregate with no fines laid as **FLAT** as possible.


Call **01580 830 800** for technical support.




1 Compact drainage stone flat and level.




2 Lay GRN20 Geogrid, lapping joins by 200mm.




3 Mark tree location.




4 Assemble RootSpace Uprights leaving a gap around tree location.




5 Position ArborGuy system as per product instructions.




6 Wrap RootSpace structure sides with GRN20 Geogrid.




7 Install RootSpace lids - leave 1mtr square gaps to ease soil filling.




8 Backfill perimeter with aggregate as specified.




9 Fill structure with soil, treading in thoroughly - install remaining RootSpace lids.



10 Slot RootDirector into RootSpace tree location.



11 Fit ArborVent aeration manifold as per product instructions.



12 Lay GLTWGNA Geonet over RootSpace, lap joins and RootDirector sides by 200mm.